


3.2 Connecting up your lighting effects


Connect all your lighting effects up using DMX cables. Connect the first one to the DMX output on the rear of the controller.

Next you need to set the dip switches on the effects so that the controller can control each one individually. Listed below are the dip switch settings for each head - note that they are different if you are connecting a Twister4 / Galactic Moon or a ClubColour.

Dip switch settings for all units except Twister4 and ClubColour



Dip switch settings for Twister 4 / Galactic Moon



Dip switch settings for ClubColour

